


SpiritShack Voice Recorder Watch – User Guide

Please read this user guide carefully before use. This device must be charged with a 5V charger. Using a 9V fast charger may damage the unit.



Recording Mode

Recording:

Unplug the headphones and push the switch to the **ON** position. The recording screen will appear, and the device will begin recording automatically.

When the screen turns off, you can press the + or – buttons to check the time.

To return to the recording screen, long-press the – button on the time display.

To switch between different clock screensavers, long-press the + button on the time display.

Saving:

Push the switch to the **OFF** position to save the recording and turn the device off.

(After saving and turning off, you can turn the watch back on to immediately play the newly recorded file.)

Note:

Do **not** connect the watch to a computer while recording, as this can cause the current recording to be lost.

Playback Mode

Playback:

1. Plug in the headphones.
2. Push the switch to the **ON** position to enter playback mode.

Pause:

In playback mode, short-press **+** and **–** together to pause.

Short-press **+** (or **–**) again to resume.

Track Selection:

Short-press **+** or **–** to move to the next or previous recording.

Volume Adjustment:

Long-press **–** to open the volume interface.

Short-press **–** to increase volume, long-press **–** to decrease it.

Menu Function:

During playback, long-press **+** to enter the menu.

Fast-Forward / Rewind Mode

1. Turn the watch **OFF**
2. Plug in the headphones
3. Turn the watch **ON**
4. Press and hold the **+** button until the recording begins playing
5. The **+** and **–** buttons will now control **rewind** and **fast-forward**

Note: Volume adjustment is disabled in this mode until you restart the watch.

Menu Function

In playback mode (with headphones connected), long-press **+** to open the menu.
Use **-** to scroll and **+** to confirm.

Time Setting

Select **Menu → Time**.

Press **+** to move between fields, and **-** to adjust values.

If no changes are made within 5 seconds, the watch saves and exits automatically.

Sound Settings

1. **Volume** — Short-press **-** to increase, long-press **-** to decrease, press **+** to confirm.
2. **Variable Speed Playback** — Short-press **-** to speed up, long-press **-** to slow down, press **+** to confirm.
3. **Equalizer** — Short-press **-** to cycle through sound effects (Rock, Funk, HipHop, Jazz, Classical, Electronic, Custom), then press **+** to confirm.

Recording Settings

1. **Recording Format** — Select **MP3** (smaller files) or **WAV** (higher quality).
2. **Bitrate** — Higher bitrates improve quality but use more storage.
3. **Voice-Activated Mode** — Records only when sound is detected.
After enabling, unplug the headphones and restart recording.
4. **Recording Scene** — Applies noise reduction based on environment.
5. **Recording Segment** — Set automatic file length (e.g., 10 minutes per file).

Delete

Deletes the **currently playing** file.

To avoid accidental deletion, pause playback before entering the menu.

Time Function

Watch Mode

When powered off, the shutdown screen appears.

Short-press **+** to switch to the clock display.

Press **+** or **-** at any time (while powered off) to view the time.

Note:

The time is not displayed constantly to save power.

Changing the Time

Time settings can be adjusted in the **Menu → Time** section.

Charging / Data Transfer

Charging

1. Insert the USB cable into the charging/data port.
2. Connect the other end to a computer USB port or a **5V, 1A maximum** charger.
Do not use fast chargers.
3. While charging, the battery icon will animate.
4. When fully charged, the icon will stop moving.

Transferring Files to a Computer

When connected to a PC or laptop, the watch will appear as a **USB drive (U-disk)**.

You can:

- Copy recordings
- Play recordings directly
- Organise or delete files

Charging and data transfer can occur at the same time when connected to a computer.

Specification

- Battery: Polymer Lithium
- Charging Time: ~1 hour
- Sampling Rate: 48 kHz
- Recording Format: MP3 / WAV
- Storage: 8GB (up to 96 hours recording)
- Bitrate: 256–1536 Kbps
- Playback Format: MP3 / WMA / WAV

Important Information

Charging:

When charging or connecting to a computer, turn the switch to **OFF**.

When disconnecting, wait for the screen to turn off before using the watch again.

Recording / Saving:

Always switch to **OFF** after recording to ensure the file is saved.

Turning off the device is the **only** way to save the file.

Recording Issues:

If recording fails, storage may be full.

Delete files on the watch or transfer them to a computer.

Unresponsive Screen:

If the screen freezes or behaves abnormally, back up important files, then open **My Computer / This PC**, right-click the device, select **Format**, choose **Quick Format**, and complete the process.

This clears the internal storage and usually resolves screen issues.

(Does not reset firmware or settings.)

No Response When Connected to a Computer:

Check the cable connection.

If still not recognised, try another USB port or another computer.

Some systems may require specific drivers.

Avoid Data Loss:

Do not connect the watch to a computer while recording, as this may cause the current file to be lost.

Back Up Recordings Regularly:

High-quality files can be large.

We recommend transferring recordings to a computer regularly.

SpiritShack cannot be responsible for loss of data if files are not backed up.